



## Installation Instructions For 2019+ BMW G20/21 M340i (B58 3.0T)

### KIT CONTENTS

NO.	DESCRIPTION	QTY
1	4" Intake Pipe	1
2	Heat Shield	1
3	Heat Shield Cover	1
4	M4 Bolt 8mm	5
5	M4 Spring Washer	3
6	M4 Washer	3
7	M8 Bolt	1
8	M8 Nut	1
9	M8 Washer	2
10	M6 Bolt	1
11	M6 Washer	2
12	M6 Nut	1
13	4 1/2" Clamps	3
14	Air Filter 102/115mm	1
15	102mm L76 Silicone Hose	1

※Do not attempt to install the intake system while the engine is hot.  
The installation may require removal of radiator fluid line that may be hot.





Figure 1: Stock air box.



Figure 4: Remove stock air box.



Figure 2: Loosen the stock tube hose clamp.



Figure 5: Remove the stock turbo inlet pipe spring, PCV and



Figure 3: Disconnect the MAF sensor.



Figure 6: Remove the stock hose.



Figure 7: Install the silicone hose.



Figure 10: Secure the heat shield bracket with M6 bolt.



Figure 8: Install the stock turbo pipe.



Figure 11: Secure the heat shield bracket with M8 bolt.



Figure 9: Install the heat shield.



Figure 12: Install the intake pipe.



Figure 13: Install the air filter.



Figure 14: Plug in the mass air flow sensor connector.



Figure 15: Install the heat shield cover and secure with M4 bolt.



Figure 16: Congratulations! You have just completed the installation of this intake system. Periodically, check the alignment of the intake, normal wear and tear can cause nuts and bolts to come loose.