

Installation Instructions For

2015+ Audi A4/A5 B9 2.0T (With MAF Sensor)

KIT CONTENTS

NO.	DESCRIPTION	QTY	
1	Silicone Tube	1	<p>Please Check the Contacts of this box immediately.</p> <p>Installing does require some mechanical skills. A qualified mechanic is always recommended.</p> <p>※Do not attempt to install the intake system while the engine is hot.</p> <p>The installation may require removal of radiator fluid line that may be hot.</p>
2	Heat Shield	1	
3	Heat Shield Cover	1	
4	Air Filter 115/70mm	1	
5	M4 Bolt 8mm	5	
6	M4 Spring Washer	5	
7	M4 Washer	5	
8	M4 Bolt 10mm	2	
9	M6 Bolt	2	
10	M6 Washer	2	
11	M6 Spring Washer	2	
12	Heat Shield Mount	2	

*All installation of parts must be performed by a trained professional.





Figure 1: Stock factory airbox.



Figure 4: Remove the factory tube.



Figure 2: Unclip the sensor.



Figure 5: Remove the factory airbox.



Figure 3: Loosen hose clamp from the factory tube.



Figure 6: Remove the MAF sensor from the factory airbox



Figure 7: Install MAF sensor on the heat shield.



Figure 9: Secure with bolt.



Figure 8: Install the heat shield mount(*2) in the rubber.



Figure 11: Install the Aosuracing silicone tube.



Figure 9: Install the heat shield.



Figure 12: Install the air filter.



Figure 13: Install the heat shield cover.



Figure 14: Connect the MAF sensor.



Figure 15: Congratulations! You have just completed the installation of this intake system. Periodically, check the alignment of the intake, normal wear and tear can cause nuts and bolts to come loose.